

CH1435
VPT
B/CB-P
TO A BOARD

CH1435
VPT
B/CB-P
NOT USED

CH1432
VPT
B/CB-P
5-MICRO

0.22 25V F.CHIP
A-3

CH12
F.CHIP

LS41
F.CHIP

CH07
F.CHIP

CH08
F.CHIP

CH04
F.CHIP

CH03
F.CHIP

CH01
F.CHIP

CH02
F.CHIP

CH05
F.CHIP

CH06
F.CHIP

CH07
F.CHIP

CH08
F.CHIP

CH09
F.CHIP

CH10
F.CHIP

CH11
F.CHIP

CH12
F.CHIP

CH13
F.CHIP

CH14
F.CHIP

CH15
F.CHIP

CH16
F.CHIP

CH17
F.CHIP

CH18
F.CHIP

CH19
F.CHIP

CH20
F.CHIP

CH21
F.CHIP

CH22
F.CHIP

CH23
F.CHIP

CH24
F.CHIP

CH25
F.CHIP

CH26
F.CHIP

CH27
F.CHIP

CH28
F.CHIP

CH29
F.CHIP

CH30
F.CHIP

CH31
F.CHIP

CH32
F.CHIP

CH33
F.CHIP

CH34
F.CHIP

CH35
F.CHIP

CH36
F.CHIP

CH37
F.CHIP

CH38
F.CHIP

CH39
F.CHIP

CH40
F.CHIP

CH41
F.CHIP

CH42
F.CHIP

CH43
F.CHIP

CH44
F.CHIP

CH45
F.CHIP

CH46
F.CHIP

CH47
F.CHIP

CH48
F.CHIP

CH49
F.CHIP

CH50
F.CHIP

CH51
F.CHIP

CH52
F.CHIP

CH53
F.CHIP

CH54
F.CHIP

CH55
F.CHIP


CH56
F.CHIP

CH57
F.CHIP

CH58
F.CHIP



CH59
F.CHIP

CH60
F.CHIP



M2 (MICRO CONTROLLER)
GEOMETRY CONTROLLER
JUNGLE H-DRIVE





CN0544
TOP
BLK
:B108-P

GND	1
T.SAW	2
+12V	3
ABL	4
N.C	5
+17.5V	6
-7.5V	7
GND	8
H.D	9
H.P	10

TO OS BOARD
CN2044

CN0525
LP
VHT

AC IN	1
NC	2
NC	3
+300V	4
NC	5
PRIM.GND	6

TO F2 BOARD
CN0925

TO VHT BOARD
CN1819

CN0504
SP
BLK
:S-MICRO

+33V	1
+14V	2
+17.5V	3
GND	4
GND	5
+7.5V	6
STBY	7
SW15.5V	8

TO A BOARD
CN0104

CN0524
SP
VHT
:S-MICRO

+17.5V	1
GND	2
NC	3

TO F2 BOARD
CN0924

CN0505
VHT
:S-MICRO


P.OFF	5
+22 V	4
-22 V	3
AUDIO GND	2


TO A BOARD
CN0105

D { HV OUT
PIN OUT
POWER SUPPLY }

D614
ESAB92-02
RECT. AUDIO-V

(KV-X2971K only)






H₁


CONTROL SW AUDIO OUT.
Y-CHROMA OUT
HEADPHONE IN

MOORE




H₂

(SIRCS RECEIVER, INDICATOR)




B-SSAE2B<X/7>-F1.




TV SONY KV-2571K/RM-831, KV-2971K/RM-831

	KV-X2571K	KV-X2971K
C802	-	-
C803	0.0022	0.0022
C823	0.47MF	1MF
C827	0.1MF	1MF
R802	0	15K
R805	15K	15K
R824	10K	10K
R832	22K	27K
R834	56K	18K
R838	33K	10K
R884	56K	56K
R891	-	18K



TV SONY KV-2571K/RM-831, KV-2971K/RM-831




B-455AE2B<X>7>-C...

C (R. G. B OUT)

TO D BOARD
1801

FV FOCUS

H. STAT




CND421
GP
WHT
:R1W1

1	+1000V
2	+200V
3	GND
4	NC
5	H1
6	H2

TO D BOARD
CNS521

1	GND
2	GND


CND002
2P
WHT
:R1W1



CND403
8P
RED
S-MICRO

1	R
2	G
3	B
4	+12V
5	E
6	IK
7	E
8	E

TO A BOARD
CND103



B-SSAE2B<X/7>-04.

